

SUPERFREEZE PIPE FREEZER PARTS LIST

SUPERFREEZE UNITS

Accessories

CAT. #	DESCRIPTION	SF-2000/F (RTE, NADC)	SF-2000R2/F (OBSOLETE)	SF-2100/F (RTE)	SF-2500 (RTE) 115V	SF-2500/F (RTE)
60776	SPRAY BOTTLE & TRIGGER	X	X	X	X	X
65942	CLAMP, PACKAGED	X	X	X	X	X
65937	VELCRO STRAP, SMALL	X	X	X		
69707	STRAP, VELCRO, LARGE				X	X

Spare Parts

CAT. #	DESCRIPTION	SF-2000/F (RTE, NADC)	SF-2000R2/F (OBSOLETE)	SF-2100/F (RTE)	SF-2500 (RTE)	SF-2500/F (RTE)
65932	SWITCH, ROCKER W/ BOOT SF	X	X	X	X	X
67617	DRIER, FILTER SF	X	X	X	X	X
65927	STRAIN RELIEF, BIG HEYCO SF	X	X	X	X	X
67592	RELAY, START, FOR SF-2000/F, 230V COMPRESSOR	X	X	X		X
67597	CAPACITOR, START, FOR SF-2000/F 230V COMPRESSOR	X	X	X		X
65922	230V/50HZ CORD SET, W/ CONNECTOR & STRAIN RELIEF	X	X	X		X
67612	1-1/4" BP, EVAPORATOR SF2100	X	X	X		
60766	SWITCH, OVERLOAD, FOR SF 230V COMPRESSOR	X	X			X
67602	CAPACITOR, RUN, FOR SF 230V COMPRESSOR	X	X			X
67607	230V/50HZ COMPRESSOR SF2000	X	X			
67582	RUBBER HOSE, 6 FT., W/O PORT. SF2000	X	X			
67577	RUBBER HOSE, 6 FT., W/PROCESS PORT SF2000	X	X			
66457	FAN, 230V/CE SF	X		X	X	X
58496	REPAIR KIT 1, SF-2000R/F	X				
60626	SWITCH, PRESSURE CONTROL SF2100/SF2500		X	X	X	X
58506	REPAIR KIT 2, SF-2000R2/F		X			
60636	COIL, CONDENSER SF2100/SF2500			X	X	X
60646	COMPRESSOR, 230V SF2100			X		
60656	CAPACITOR, RUN SF2100			X		
60666	PROTECTOR, OVERLOAD, P10MU SF2100			X		
60676	HOSE, RUBBER, W/ CAPTUBE, ADP, ACC. SF2100			X		
60686	HOSE, RUBBER, W/ CAPTUBE & ADAPTER SF2100			X		
60696	RUBBER HOSE, ONLY, 6 FT. SF2100			X		
60706	2" EVAPORATOR SF2500				X	X
60716	HOSE, RUBBER W/ CAPTUBE, ADP, ACC. SF2500				X	X
60726	HOSE, RUBBER W/ CAPTUBE & ADAPTOR SF2500				X	X
60736	RUBBER HOSE, ONLY, 8.5 FT. SF2500				X	X
60746	COMPRESSOR, 230V SF2500					X
60756	FAN, 115V SF2500				X	